

## Q-MASK™ SM4000™ STRIPPABLE MASKING

## ALL BRANDS OF MASKING ARE NOT COMPATABLE !!!

## MIXING DIFFERENT BRANDS TOGETHER WILL RESULT IN CLOGGED SPRAY EQUIPMENT AND CONGEALLED MATERIAL IN HOSES.

## FIRST TIME EQUIPMENT PREPARATION INSTRUCTIONS

ALL PUMPS, HOSES AND SPRAY GUNS MUST BE FLUSHED WITH LARGE VOLUMES OF WATER TO REMOVE ALL OTHER BRANDS OF MASKING OR DRIED RESIDUE IN HOSES.

CONTINUE FLUSHING EQUIPMENT WITH WATER UNTIL WATER "RUNS CLEAR" FOR SEVERAL MINUTES.

BEGIN PUMPING QMASK SM4000 THRU EQUIPMENT INTO <u>SPARE CONTAINER</u> UNTIL ALL <u>WATER</u> HAS BEEN REMOVED FROM SPRAY EQUIPMENT.

WHEN MASKING PUMPS OR SPRAYS THRU EQUIPMENT AT <u>ORIGINAL SUPPLIED VISCOSITY</u> BEGIN APPLYING ON PLASTIC SUBSTRATE.

**NOTE:** IF ANY WATER IS TRAPPED IN LINES OR HOSES, MASKING WILL <u>APPEAR THIN</u> UNTIL IT IS COMPLETELY PURGED FROM THE SYSTEM.

Always test surface preparation, primer and topcoat compatibility to determine acceptability before any production run.

Disclaimer: Technical information and suggested uses are believed to be reliable by QH&F Ltd., but such information or suggestions do not constitute a warranty. QH&F Ltd. has no control over the conditions under which the product is stored, handled, used or applied. Buyers must determine for themselves the suitability of each product for their specific use.

® is a registered trademark and ™ is a trademark of Quill Hair & Ferrule LTD. Copyright © 2009. Quill Hair and Ferrule LTD. All Rights Reserved.